

### **DATA TRANSMISSION**

1



# Introduction

- Data into a computer (via a keyboard) is encoded by the electronics within the keyboard into an equivalent binary-coded pattern using standard coding schemes:
- Two most common schemes:
  - EBCDIC (Extended Binary Coded Decimal Interchange Code): 8-bit code
  - ASCII ((American Standards Committee for Information Interchange): 7-bit code



### **EBCDIC**

- Extended Binary Coded Decimal Interchange Code
- 8-bit character code developed by IBM
  - used for data communication, processing and storage
  - extended earlier proprietary 6-bit BCD code
  - designed for backward compatibility or marketing?
  - still in use today on some mainframes and legacy systems.
- Allows for 256 different character representations  $(2^8)$ 
  - includes upper and lower case
  - lots of special characters (non-printable)
  - lots of blank (non-used codes)
    - assigned to international characters in various versions
  - used with/without parity (block transmissions)

3



#### **EBCDIC Code**

7													9			
1123	0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1
0000	NUL	SOH	STX	ETX	PF	нт	LC	DEL				VT	FF	CR	so	SI
0001	DLE	DCI	DC2	DC3	RES	NL.	BS	II.	CAN	EM			IFS	IOS	IRS	IUS
010			FS		BYP	LF	ЕОВ	PRE			SM			ENQ	ACK	BE
0011			SYN		PN	RS	UC	EOT					DC4	NAK		SUI
100	SP										· ·		<	-	+	1
101	S.											s		)		-
110	-	,											96		-	- 2
111	-	L^									-		69			-
1000		0	ь	e	d	e	f	E	h	ì	-	Ť			-	
1001		1	k	1	m	n		P	9	ŕ	-	-				$\vdash$
1010		~		÷		n v	-	-	-	-						
	_	~	N		U	v	w	х	У	z	_	-				-
011																
1100	-{	Α	В	C	D	Е	F	G	н	1						
1101	)	3	K	L	М	N	0	P	Q	R						
				т	U	v	w	x	Y	z						
1110			S													
IIII			2 rt, simp	3	4 the ch									e row f		0. 1.
IIII	o read i	his cha	2 rt, simp	3	4 the ch	aract	er on th	e chart his is or	, then l	ook to of man				e row f		0. 1.
Vote: T	o read i	his cha	2 rt, simp he colu	3	4 the ch bits 4, 5	eracti , 6, a EBC	er on the	ne chart his is or	, then leady one of	ook to of man			mplem	entation	sefEB	0. 1.
Note: T	o read to the	his cha	2 rt, simp he colu	3	4 the ch	EBC	er on the	e chart his is or secial c	, then leady one of	ook to of man			mplem PF	Punc	sefEB	0. 1.
ACK BEL	Ackr Bell	his cha top of t	2 rt, simp he colu	3	4 the ch bits 4, 5	EBC	or on the	ne chart his is or necial e Fransm	, then leady one of	ook to of man			pp PN	Punc Punc	h Off	
ACK BEL BS	Ackr Bell Back	his cha top of t sowledg	2 rt, simp he colu	3	4 the ch bits 4, 5	EBC	DIC sp	ne churt his is or secial e Fransm Text red	, then leady one of	ook to of man			PF PN PRE	Punci Punci Prefit	h Off	0. 1.
ACK BEL BS BYP	Ackr Bell Back Byps	his cha top of t sowledg	2 rt, simp he colu	3	4 the ch bits 4, 5	EBC	DIC sp	secial e Pransm Text red sarator	, then I ally one of haracter ission	ook to of man			PF PN PRE RES	Punci Punci Prefit Reste	h Off h On c	0. I.
ACK BEL BS BYP CAN	Ackr Bell Back Bype Canc	his cha top of t sowledg space	2 rt, simp the colu	3	4 the ch bits 4, 5 EO ET? FF	EBC	DIC sp and of and of an	se chart his is or secial e Transm Text red sarator ital Tab	, then buly one of	ook to of man			PF PN PRE RES RS	Punci Punci Prefit Reste Read	h Off h On c	0. I.
ACK BEL BS BYP CAN CR	Ackr Bell Back Bype Canc	his cha top of t whedg space ass el age Rei	2 rt, simp the colu	3	EO' FF FS HT IFS	EBC	DIC sp End of Sorm Fi	e chart his is or rectal e Fransm Text red surator ital Tab	, then I ally one of haracter ission	ook to of man	y pose		PF PN PRE RES RS SI	Punci Punci Prefit Reste Read Shift	h Off h On c ore er Stop In	0, 1, icDi
ACK BEL BS BYP CAN CR DCI	Ackr Bell Back Byp Cane Carri Devi	his cha top of t sowledg space	2 rt, simp the colu	3	EO ET? FF FS HT IFS IGS	EBC	End of Sorm Forms of Forms of The Sorm Forms of	e chart his is or rectal e Fransm Text red surator ital Tab	, then buly one of	ook to of man	y pose		PF PN PRE RES RS	Punci Punci Prefit Reste Read Shift	h Off h On c ore er Stop In Messay	0, 1, icDi
ACK BEL BS BYP CAN CR DC1 DC2	Ackr Bell Back Bype Carri Devi	this char top of t sowledge space as sol age Rei se Cont	2 rt, simp the colu ternent turn red 1 red 2	3	EO' FF FS HT IFS	EBC	DIC sp End of End of End of Form For File Sep Horizon Informa	ne chari his is or Peransum Fext red Narator stal Tab stion Gi	then buyone in the second seco	ook to of man	s, bose		PF PN PRE RES RS SI SM SO	Punci Punci Prefii Reste Read Shift Start Shift	h Off h On c ore er Stop In Messay	0. I. ICDI
ACK BEL BS BYP CAN CR DC1 DC2 DC3	Ackr Bell Back Byps Canc Carr Devi Devi	this char top of t space ss el age Rei ce Cont ce Cont	2 rt, simp the colu ternent turn red 1 rol 2 rol 3	3	EOT FF FS HT IFS IGS IL IRS	EBC	DIC sp End of End of Form Felle Sep Horizon Information of the Informa	ne chart his is or rectal e Fransm Text red surator real Tab stion Fi ition Ga stion Re	then buly one of the second se	ook to of man	s, bose		PF PN PRE RES RS SI SM SO SOH	Punci Punci Prefir Reste Read Shift Start Shift Start	h Off h On core er Stop In Messay Out of Hea	0. I. ICDI
ACK BEL BS CAN CR DC1 DC2 DC3 DC4	Ackr Bell Back Byps Canc Carr Devi Devi	this cha top of t sowledg space age Re- ce Com ce Com ce Com	2 rt, simp the colu ternent turn red 1 rol 2 rol 3	3	EO' ET? FF HT IFS IGS	EBC	DIC sp End of End of Form Felle Sep Horizon Information of the Informa	ne chart his is or recial c Franson Text red sarator tal Tab stion Fi stion Ga stion Us	then buyone in the second seco	ook to of man	s, bose		PF PN PRE RES RS SI SM SO	Punci Punci Prefir Reste Read Shift Start Start Space	h Off h On core er Stop In Messay Out of Hea	o. 1. iCDI
ACK BEL BS BYP CAN CR DC1 DC2 DC3	Ackr Bell Back Byps Canc Carri Devi Devi Devi Devi Dele	this cha top of t space ass cl age Rei ce Cont ce Cont ce Cont	2 rt. simp the colu turn rol 1 rol 2 rol 3 rol 4	3	EOT ET? FF HT IFS IGS IUS	EBC	DIC sp End of Send of	ne chart his is on pecial e Pransm Text red surator tial Tab tion Fi tion Re tion Re tion Re	then buly one of the second se	ook to of man	s, bose		PF PN PRE RES RS SI SM SO SOH SP	Punci Punci Prefir Reste Read Shift Start Start Space	h Off h On ore er Stop In Messay Out of Hea	o. 1. iCDI
ACK BEL BS BYP CAN CR DC1 DC2 DC3 DC4 DEL	Ackr Bell Back Bypt Canc Carri Devi Devi Devi Dele Data	this char top of t space ass el age Rei ce Com ce Cont te	2 rt, simp the colu term red 1 red 2 red 3 red 4 scape	3	EOT FF FS HT IFS IL IRS IUS LUS	EBC	DIC sp End of Sorm Forms form Forms of Sorm Forms forms of Sorms of Sorms of Sorms forms of Sorms of Sorms of Sorms of Sorms of S	ne chart his is on pecial e Pransm Text red surator tal Tab tion Fi tion Re tion Re tion Re tion Re	a then I dly one of haracter ission le Separ oup Se cord Se ait Separ	ook to of man is	s, bose		PF PN PRE RES RS SI SM SOH SP STX SUB	Punci Punci Prefix Reste Read Shift Start Shart Space Start Subst	h Off h On ore er Stop In Messay Out of Hea e of Text	D. I. ICDI
ACK BEL BS BYP CAN CR DC1 DC2 DC3 DC4	Ackr Bell Back Bypt Canc Carri Devi Devi Devi Dele Data	this char top of t space ass el age Rei ce Com ce Com ce Com ce Com ce Com ce Com	2 rt, simp the colu term red 1 red 2 red 3 red 4 scape	3	4  EOT ETZ FF FS HT HFS HGS IL HRS LC	EBC	DIC sp End of Sorm Forms form Forms of Sorm Forms forms of Sorms of Sorms of Sorms forms of Sorms of Sorms of Sorms of Sorms of S	ne chart his is on necial e Transm Text red surator tal Tab tion Fi tion Go tion Us Case ed	then buly one of the second se	ook to of man is	s, bose		PF PN PRE RES RS SI SO SOH SP STX	Punci Punci Prefix Resto Read Shift Start Space Start Substart Sub	h Off h On ore er Stop In Messay Out of Hea	D. I. ICDI



## **ASCII CODE**

- 7-bit code developed by the American National Standards Institute (ANSI)
  - most popular data communication character code today
- Allows for 128 different character representations (2<sup>7</sup>)
  - includes upper and lower case
  - lots of special characters (non-printable)
  - generally used with an added parity bit
  - better binary ordering of characters than EBCDIC
- Extended ASCII uses 8 data bits and no parity
  - Used for processing and storage of data
  - Allows for international characters
  - 8th bit stripped of for transmission of standard character set 5



## **ASCII Code**

Bits 7654321	Character	Bits 7654321	Character	Bits 7654321	Character	Bits 7654321	Character
0000000	NUL	0100000	SP	1000000	@	1100000	
0000001	SOH	0100001	!	1000001	A	1100001	a
0000010	STX	0100010	**	1000010	В	1100010	ь
0000011	ETX	0100011	#	1000011	C	1100011	c
0000100	EOT	0100100	S	1000100	D	1100100	d
0000101	ENQ	0100101	%	1000101	E	1100101	e
0000110	ACK	0100110	&	1000110	F	1100110	f
0000111	BEL	0100111		1000111	G	1100111	g
0001000	BS	0101000	(	1001000	H	1101000	h
0001001	HT	0101001	)	1001001	1	1101001	i
0001010	LF	0101010		1001010	J	1101010	j
0001011	VT	0101011	+	1001011	K	1101011	k
0001100	FF	0101100		1001100	L	1101100	1
0001101	CR	0101101	-	1001101	M	1101101	m
0001110	SO	0101110		1001110	N	1101110	n
0001111	SI	0101111	/	1001111	0	1101111	O
0010000	DLE	0110000	0	1010000	P	1110000	p
0010001	DC1	0110001	1	1010001	O	1110001	q
0010010	DC2	0110010	2	1010010	R	1110010	r
0010011	DC3	0110011	3	1010011	S	1110011	s
0010100	DC4	0110100	4	1010100	T	1110100	t
0010101	NAK	0110101	5	1010101	U	1110101	u
0010110	SYN	0110110	6	1010110	v	1110110	v
0010111	ETB	0110111	7	1010111	w	1110111	w
0011000	CAN	0111000	8	1011000	X	1111000	x
0011001	EM	0111001	9	1011001	Y	1111001	y
0011010	SUB	0111010	1	1011010	Z	1111010	z
0011011	ESC	0111011	:	1011011	]	1111011	1
0011100	FS	0111100	<	1011100	,	1111100	ì
0011101	GS	0111101	=	1011101	1	1111101	1
0011110	RS	0111110	>	1011110	^	1111110	~
0011111	US	0111111	?	1011111	_	1111111	DEL



### **ASCII Non-Printable Codes**


ASCII control characters									
BEL	Bell	EM	End of Medium						
CAN	Cancel	ESC	Escape						
DC1	Device Control 1	NUL	Null						
DC2	Device Control 2	SI	Shift In						
DC3	Device Control 3	SO	Shift Out						
DC4	Device Control 4	SUB	Substitute						
DEL	Delete								
	Control	codes							
ACK	Acknowledge	ETX	End of Text						
DLE	Data Link Escape	NAK	Negative Acknowledge						
ENQ	Enquiry	SOH	Start of Heading						
EOT	End of Transmission	STX	Start of Text						
ETB	End of Transmission Block	SYN	Synchronous Idle						
	Format	effectors							
BS	Backspace	HT	Horizontal Tabulation						
CR	Carriage Return	LF	Line Feed						
FF	Form Feed	VT	Vertical Tabulation						
	Information	n separato	rs						
FS	File Separator	RS	Record Separator						
GS	Group Separator	US	Unit Separator						


7



## **Bit Transmission**

- Parallel mode: uses several wires, each wire sending one bit at the same time as the others.
- Serial mode: sends bit by bit over a single line
- Serial mode is slower than parallel, but can be used over longer distances because the bits stay in the order they were sent, while bits sent in parallel mode tend to spread out over long distances.










## **Communication Modes**

- Simplex: Used when data is to be transmitted in one direction only
- Half-Duplex: Used when the two interconnected devices wish to exchange information alternately (only one device can transmit at a time)
- Full-Duplex: Used when data is to be exchanged between the two connected devices in both directions simultaneously









#### Transmission Modes

- For the receiver to decode and interpret bit pattern correctly, it must be able to determine
  - The start of each bit cell period → bit / clock synchronization
  - The start and end of each elements (character / byte) → character / byte synchronization
  - The start and end of each complete message block → frame synchronization

15



#### **Transmission Modes**

- Timing problems require a mechanism to synchronize the transmitter and receiver
- Two solutions
  - Asynchronous transmission: Transmitter and receiver clocks are independent
  - Synchronous transmission: Transmitter and receiver clocks are synchronized



- Data transmitted on character at a time
  - 5 to 8 bits
- Timing only needs maintaining within each character
- Resynchronize with each character

17



# **Asynchronous Transmission**

- In a steady stream, interval between characters is uniform (length of stop element)
- In idle state, receiver looks for transition 1 to 0
- Then samples next seven intervals (char length)
- Then looks for next 1 to 0 for next char
- Simple
- Cheap
- Overhead of 2 or 3 bits per char (~20%)
- Good for data with large gaps (keyboard)



- Block of data transmitted without start or stop bits
- Clocks must be synchronized
- Can use separate clock line
  - Good over short distances
  - Subject to impairments

19




## **Error Control and Flow Control**

- Error control: schemes and procedures to detect and correct the occurrence of transmission errors
- Flow control: The control of the flow of information between two DTEs



- Transmission control circuits within DTE must perform the following functions:
  - Parallel-to-serial conversion (PISO) of each character / byte in preparation for its transmission
  - Serial-to-parallel conversion (SIPO) of each received character / byte in preparation for its storage and processing
  - A means for receiver to achieve bit, character and frame synchronization
  - The generation of suitable error check digits for error detection







- Bit synchronization
  - Start bit & stop bit
  - Receiver clock samples the incoming signal as near to the center of the bit cell as possible
- Character synchronization
  - Number of bits / character
- Frame synchronization
  - Control character: STX & EXT


23




# Asynchronous (Diagram)











- Block of data transmitted without start or stop bits
- Each frame is transmitted as a contiguous stream of binary digits
- Clocks must be synchronized



- Bit synchronization
  - Clock encoding and extraction
  - Digital Phase-lock-loop (DPLL)
  - Hybrid
- Frame synchronization
  - Character-oriented
  - Bit-oriented


29



## Bit Synchronization

- The receiver obtains (and maintains) bit synchronization in one of two ways
  - The clock (timing) information is embedded into the transmitted signal and subsequently extracted by the receiver → clock encoding and extraction
  - Receiver has a local lock (as with asynchronous transmission) but this time is kept in synchronism with the receiver signal by digital phase-lock-loop (DPLL) → DPLL
  - Hybrid schemes that exploit both methods → Hybrid






31



# Bit Synchronization

- Bit synchronization
  - Clock encoding and extraction: embbeding timing (clock) information into a transmitted bit stream → RZ, Manchester, differential Manchester encoding






- Bit synchronization
  - DPLL: encoding the information in such a way that there are always sufficient bit transition (1 → 0 or 0 → 1) in transmitted waveform to enable the receiver clock to be resynchronized at frequent intervals
    - passing the data to be transmitted through a scrambler which randomizes the transmitted bit stream, removing contiguous strings of 1s or 0s
    - Encoding data in such a way that suitable transitions will always be present



- Bit synchronization
  - DPLL
    - DPLL' clock is 32 times the bit rate used on the data link
    - If there is no transition on the line, DPLL simply generates a sampling pulse every 32 clock periods after the previous one



35



# Synchronous Transmission

- Bit synchronization
  - DPLL
    - When a transition is detected, the time interval between the previously generated sampling pulse and the next is determined according to the position of the transition relative to where DPLL thought it should be occur


Drift = 
$$t_{actual-transition} - (t_{sample} + N/2)$$

Adjust to the next sampling pulse depending on the amount of drift



#### Bit synchronization

DPLL



t <sub>sample</sub>	tactual	$\Delta (N/2 = 16)$	drift	Segment	sample	adjustment
40	60	20	+4	E	too early	+2
40	56	16	0	C	OK	0
40	50	10	-6	A	too late	-2

segment of actual signal transition	next anticipated sampling pulse	sampling adjustment	actual next
A	too late	- 2 ticks	30
В	late	-1 tick	31
C	OK	none	32
D	early	+1 tick	33
E	too early	+2 ticks	34

37





# Synchronous Transmission

- Bit synchronization
  - DPLL
    - To achieve this, each bit period is divided into five segments, shown as A, B, C, D and E.
      - A transition occurring in segment A and E indicates that the previous sampling pulse was too early relative to the transition → typical division A = E = 10
      - Transitions in segments B and E are clearly nearer to the assumed transition and hence the relative adjustment are less → typical division B = D = 4
      - A transition in segment C is deemed to be close enough to the assumed transition to warranty no adjusment → typical division C = 4



- Bit synchronization
  - DPLL
    - In the worst case, DPLL requires 10 bit transitions to converge to the nominal bit center of a waveform: 5 bit periods of coarse adjustment (±2), 5 bit periods of fine adjustment (±1)








- Bit synchronization
  - DPLL

Examples of synchronization on signal transitions

		-	•		-		
	t <sub>sample</sub>	tactual	$\Delta (N/2 = 16)$	drift	Segment	Sample	Adjustment
1.	0	16	16	0	C	OK	0
2.	32	47	15	-1	C	OK	0
3.	64	78	14	-2	В	too late	-1






# **Synchronous Transmission**


- Bit synchronization
  - DPLL


Examples of synchronization on signal transitions

	t <sub>sample</sub>	tactual	$\Delta (N/2 = 16)$	drift	Segment	Sample	Adjustment
3.	64	78	14	-2	В	too late	-1
4.	95	110	15	-1	C	OK	0
5.	127	142	15	-1	С	OK	0
6.	159	174	15	-1	С	OK	0



42








- Bit synchronization
  - DPLL

Started from worst possible situation: drift = ±16 DPLL clock cycles

	t <sub>sample</sub>	tactual	$\Delta (N/2 = 16)$	drift	Segment	Sample	Adjustment
5.	120	128	8	-8	A	too late	-2
6.	150	160	10	-6	A	too late	-2
7.	180	192	12	-4	В	too late	-1)
8.	211	224	13	-3	В	too late	-1






# Synchronous Transmision


- Bit synchronization
  - DPLL
    - Line Coding: NRZ, AMI, HDB3, B3ZS, B6ZS, B8ZS, 4B3T, 2B1Q
      - Mean (DC) level of the transmitted signal is zero
      - Bandwidth
      - Bit rate
      - Error detection

46





- Bit synchronization
  - Hybrid schemes: is used as the bit rate increases
    - Uses a combination of Manchester encoding and a DPLL






# Frame Synchronization


- 2 types of synchronous transmission control scheme:
  - Character-oriented: is used primarily for the transmission of blocks of characters
  - Bit-oriented: is used for the transmission of frames comprising either printable characters or binary data





# Frame Synchronization


- Character-oriented:
  - Transmitter adds two or more transmission control characters, known as synchronous idle or SYN characters before block of characters
  - SYN characters have 2 functions:
    - Bit synchronization
    - Character synchronization



























## Frame Synchronization


#### Bit-oriented


- The start and end of a frame are both signaled by the same unique 8-bit pattern 01111110, known as the flag byte or flag pattern
- To enable the receiver to obtain and maintain bit synchronism, the transmitter sends a string of idle bytes (each comprising 01111111) preceding the start-of-frame flag
- To achieve data transparency, zero bit insertion or bit stuffing is used


61













#### **Error Detection Methods**

- Forward error control
  - Detect errors when they are present and determine (if possible) where in the received bit stream the errors are
- Feedback (backward) error control
  - Retransmission control scheme is used to request that another, hopefully correct, copy of the information to be sent
- → Feedback error control is the predominant method used in the types of data communications

67




#### **Error Detection Methods**


- Feedback error control can be divided into two parts:
  - The techniques that are used to achieve reliable error detection (FEC)
  - The control algorithm that are available to perform the associated retransmission control schemes



### **Error Detection Methods**

- Two factors that determine the type of error detection scheme used:
  - Bit Error Rate (BER)
  - Type of errors
    - Single-bit error: errors occur as random singlebit errors, adjacent bits not affected
    - Burst errors: group of contiguous string of bit errors
      - Length B
      - Contiguous sequence of B bits in which first last and any number of intermediate bits in error








# What is Coding?


- Coding is mapping of binary source (usually) output sequences of length k into binary channel input sequences n (>k)
- A block code is denoted by (n,k)
- Binary coding produces 2<sup>k</sup> codewords of length n. Extra bits in codewords are used for error detection/correction



#### Representing Codes by Vector

- Code strength is measured by Hamming distance that tells how different code words are:
  - Codes are more powerful when their minimum Hamming distance  $d_{min}$  (over all codes in the code family) is large
- Hamming distance d(X,Y) is the number of bits that are different between code words
- (*n,k*) codes can be mapped into *n*-dimensional grid:







73


# 4

# Hamming distance: The decision sphere interpretation

Consider two block code (n,k) words  $c_1$  and  $c_2$  at the Hamming distance in the n-dimensional code space:









#### **Error Detection Methods**


- Parity check
- Block sum check
- Cyclic Redundant Check

75



## Parity Checking

- Used with asynchronous and characteroriented synchronous transmission
- Transmitter adds an additional bit the parity bit – to each transmission character prior to transmission
- Two parity checking methods:
  - Even parity: The total number of 1 bits is even
  - Odd parity: The total number of 0 bits is odd





# **Parity Checking**

- Detect all single-bit errors
- Does not detect 2-bit errors



#### **Block Sum Check**


• When blocks of characters (frames) being transmitted, we can achieve an extension to the error-detecting capabilities obtained from a single parity bit per character (byte) by using an addition set of parity bits computed from the complete block of characters (byte) in frame.

79



#### **Block Sum Check**


- In this method:
  - Each character (byte) in the frame is assigned a parity bit as before (transverse or row parity)
  - An extra bit is computed for each bit position (longitudinal or column parity) in the complete frame.
- The set of parity bits for each column is referred to as the block (sum) check character








## **Block Sum Check**

 Detect 2 bit errors in a character only if 2 bit errors occur in the same column at the same time.











#### Cyclic Redundant Check

- Parity or block sum check does not provide a reliable detection schemes against error bursts → the most common alternative is based on the us of polynomial codes
- Polynomial codes are used with frame (or block) transmission scheme
- A single set of check digits is generated (computed) for each frame transmitted based on the content of the frame, and is appended by the transmitter to the tail of the frame
- The computed check digits are referred to as the Frame Check Sequence (FCS) or Cyclic Redundant Check (CRC)


87





## Cyclic Redundant Check

- M(x) be a k-bit number (the message to be transmitted)
- G(x) be an (n+1)-bit number (the divisor or generator)
- R(x) be an n-bit number (the remainder)
- T(x) be transmitted bit

$$\rightarrow$$
 T(x) = x<sup>n</sup> . M(x) + R(x)









## Cyclic Redundant Check

- Detect
  - All single-bit errors
  - All double-bit errors
  - All odd number of bit errors
  - All error bursts < R</p>
  - Most error burst ≥ R



### **Data Compression**

- Packed decimal
- Relative encoding
- Character suppression
- Huffman coding
- Run-length coding

93



## **Huffman Coding**

- Huffman coding exploits the property that not all symbols in a transmitted frame occur with the same frequency.
- Encoding scheme: most common characters are encoded using fewer bits than less frequent characters → statistical encoding.
- Variable number of bits per character → used in bit-oriented transmission.



#### **Huffman Coding**

- The character string to be transmitted is analyzed and the character types and their relative frequency determined.
- The coding operation involves creating an unbalanced tree with some branches
   → Huffman code tree (binary tree)

95



## Huffman coding

- Binary tree with branches assigned the value 0 or 1
  - The base of the tree, the geometric top, is known as the root node
  - The point at which a branch divides is known as the branch node
  - The termination point of a branch is known as a leaf node



## **Huffman Coding**

- The theoretical minimum average number of bits per codeword to transfer the message string is known as the entropy, *H*, of the message.
- Entropy *H* (bits per codeword) can be calculated:


$$H = -\sum_{i=1}^{n} P_i \log_2 P_i \quad ($$

- N is the number of characters
- P<sub>i</sub> is the probability of character i

97




## **Huffman Coding**





### Run-length Coding

- Used in black and white Facsimile machine
- It scans a page with a vertical resolution of 3.85 or 7.7 lines per millimeter – approximately 100 or 200 lines per inche.
- Each scan line is digitized at the rate of 8.05 picture element or pels per millimeter a 0 for white and 1 for black
- A typical scanned page produces about 2 million binary digits






## Run-length Coding

- The codewords are fixed and grouped into 2 separate groups: the termination-codes and the make-up codes
- To enable the receiver to regain synchronism, each scanned line is terminated with a known end-of-line (EOL) code.
- String of six EOLs indicate the end of a page

101





#### **Transmission Control Circuits**

- Universal asynchronous receiver transmitter (UART)
  - Start and stop bit insertion and deletion
  - Bit (clock synchronization)
  - Character synchronization
  - Parity bit generation and checking per character (BCC computed by controlling device)

103



#### **Transmission Control Circuits**

- Universal synchronous receiver transmitter
  - Low bit rate DPLL clock synchronization
  - Character synchronization
  - Synchronous idle character generation
  - Parity generation and checking per character (BCC computed by controlling device)



#### **Transmission Control Circuits**

- Universal synchronous / asynchronous receiver transmitter (USART)
  - Can be programmed to operate as either a UART or USRT
  - Has all programmable features of both devices

105



## **Transmission Control Circuits**

- Bit-oriented protocol circuits (BOPs)
  - Opening and closing flag insertion and deletion
  - Zero bit insertion and deletion
  - CRC generation and checking
  - Idle pattern generation



#### **Transmission Control Circuits**


- Universal communication control circuits
  - Can be programmed to operate either UART, a USRT or a BOP
  - Has all the programmable features of each circuit


107





# Communications Control Devices


- Simple terminal networks
- Multiplexer-based networks













# **Block-mode Devices**

- Multidrop (multipoint) lines
- Cluster controller
- Hub-polling

